

FGC PRESET CAM-OVER WRENCH OPERATING INSTRUCTIONS

Rev 2.0

Register Your FGC Wrench

Register your Mountz FGC wrench now to unlock exclusive benefits! Gain access to timely updates, ensuring your product is always up-to-date, along with comprehensive resources.

Stay ahead with our commitment to providing you with the best experience possible. Register today for peace of mind and unparalleled support. Scan the QR to register your product(s).



SCAN ME

Adjusting the Torque Setting for a Preset Value

The FGC has no external adjustment scale and must be preset using a torque analyzer or torque sensor. If the tool has not been preset to a set torque value, follow the directions for adjusting the torque setting before using the wrench.

1. Insert the hex key into the end cap, turn it in an anti-clockwise direction, and remove it from the wrench.

FGC-5 and FGC-10 Models*: use 5/32" hex key

FGC-30, FGC-75 and FGC-125 Models: use 1/4" hex key

***Note:** Some older versions of these models may require 1/4" hex key



2. Insert the hex key into the torque adjuster mechanism, push in and turn the hex key clockwise to increase torque and counter-clockwise to decrease torque.

FGC-5 and FGC-10 Models: use 5/32" hex key

FGC-30, FGC-75 and FGC-125 Models: use 1/4" hex key



3. Cycle wrench 10 times before taking readings.
4. Take 10 consistent readings on the torque analyzer to confirm the torque setting. Do not adjust torque above or below the recommended torque ranges for the torque wrench or torque analyzer. Hand tighten the end-cap back on wrench using the hex key.

Note: Do not adjust the torque setting while the wrench is connected to a torque analyzer or torque sensor, as you can over torque and damage the sensor.

Applying Torque

1. Tighten the fastener or bolt by applying an even pull. The wrench should be kept at 90 degrees to the axis of the bolt during tightening. When pre-set torque is reached, the wrench will 'slip.'
2. The wrench will automatically reset itself for the next application.
3. Its unique cam-over design makes it impossible to overtighten beyond the preset load.

Calibrating Cam-Over Wrench

To calibrate the cam-over wrench, either use a torque analyzer or torque sensor within the torque wrenches, calibrate torque in "Peak" mode with a torque tester or torque sensor. Make sure to and smoothly.

1. Select a torque tester or torque sensor that covers the torque range of the wrench. Connect the tester or torque sensor. Use the appropriate adapters as needed.
2. Apply torque clockwise slowly until the wrench 'slips' and note reading.
3. Adjust the wrench to the required torque setting as described above.
4. Test and repeat adjustments as necessary to obtain desired torque value.
5. Recalibrate the cam-over wrench at prescribed intervals.



Maintenance Schedule

Like an automobile, torque wrenches contain moving parts that require periodic servicing and lubrication.

Period Between Resetting of Torque

10,000 fastening operations. It is acknowledged that some tools may achieve 10,000 operations in a relatively short period of time. Under these circumstances, the user may decide, with the benefit of their experience, to increase the period between calibration intervals.

Routine Maintenance

After 50,000 operations, strip, clean, and re-grease the spring, bearings and internal components. Any worn components should be replaced.

Note: Any tool that is dismantled during its life must be re-lubricated in accordance with the Mountz recommendations. Do not clean tools by immersing them in a solvent, as this will destroy the internal lubrication and cause tool's failure.

Testing and Servicing

Torque tools go out of calibration with use. Calibrating a torque tool is a fine-tuning process of bringing the tool back within its tolerance. Regular torque calibration of a cam-over wrench ensures accuracy, repeatable tool performance, and adherence to international standards.

We recommend a general once a year calibration interval. However, the user's organization must determine suitable intervals based on equipment performance, application, degree of usage, and management objectives.

Mountz Calibration and Repair Services

Mountz Inc. features an experienced calibration and repair staff. Our trained technicians can calibrate and repair almost any tool. Mountz provides rapid service with quality that you can trust as we offer three state-of-the-art calibration labs and repair facilities.

About Mountz

Mountz, The Torque Tool Specialists®, has been a leader in the torque tool industry for 60 years. Engineered in the Silicon Valley and serving the globe, Mountz focuses on delivering high-quality torque products, services, and solutions to ensure customers can always proceed with confidence. We are committed to forging a safer world through precision and accuracy and by innovating every day.

Mountz Service Locations

Eastern Service Center

19051 Underwood Rd.
Foley, AL 36535
Phone: (251) 943-4125
Fax: (251) 943-4979

Western Service Center

1080 N.11th Street
San Jose, CA 95112
Phone: (408) 292-2214
Fax: (408) 292-2733

UK Service Center

Pier Copse Courtyard,
Milland Lane,
Liphook, Hampshire, GU30
7JN, UK
Phone: 00 44 1428 741756

www.mountztorque.com